
External Power Control (Coil Converter)

- Interface unit to be used by MagPro Compact only.
- The unit is mounted on the front of MagPro Compact between the stimulator and the coil
- The external power control is for coils without controls in the coil handle. Instead, the control is carried out from the external power control.



Technical Data

Coils

All coils except
C-100, C-B60 and MMC-140-II

Note:

F- and Cool-coils types are not
recommended for MagPro Compact

Weight

140g

Ordering Number

9016E045-